

C8051FxxxDK DEVELOPMENT KIT QUICK-START GUIDE FOR KITS FEATURING THE UNIFIED DEVELOPMENT PLATFORM (UDP)

Kit Contents

There are four varieties of general purpose UDP development kits. The content of these kits is listed below:


Development Kit

- The specific UDP MCU card.
- Silicon Laboratories USB Debug Adapter.
- Supporting cables.
- C8051FxxxDK Development Kit CD.
- C8051FxxxDK Quick Start Guide (this document).




Development Kit with Pico Board

- UPPI Pico Board for the MCU.
- The specific UDP MCU card.
- Silicon Laboratories USB Debug Adapter.
- Supporting cables.
- C8051FxxxDK Development Kit CD.
- C8051FxxxDK Quick Start Guide (this document).




Enhanced Development Kit

- The specific UDP MCU card.
- UDP Motherboard.
- The specific kit I/O card.
- Silicon Laboratories USB Debug Adapter.
- Supporting cables.
- C8051FxxxDK Development Kit CD.
- C8051FxxxDK Quick Start Guide (this document).











Enhanced Development Kit with Pico Board






- UPPI Pico Board for the MCU.
- The specific UDP MCU card.
- UDP Motherboard.
- The specific kit I/O card.
- Silicon Laboratories USB Debug Adapter.
- Supporting cables.
- C8051FxxxDK Development Kit CD.
- C8051FxxxDK Quick Start Guide (this document).







Hardware Setup with the UDP Motherboard





Hardware Setup with the MCU Card Alone



Software Installation













Using the Silicon Labs IDE

- 1** Open the project file "*<Family>_Blinky_C.wsp*" located at "*C:\SiLabs\WCUExamples\<Family>_Blinky*"
 
- 2** Select "Connection Options..." from the "Options" Menu.
 

Select USB Debug Adapter

Select the correct debug interface

C8051F0xx	→	JTAG
C8051F1xx	→	JTAG
C8051F2xx	→	JTAG
C8051F3xx	→	C2
C8051F4xx	→	C2
C8051F5xx	→	C2
C8051F9xx	→	C2
- 3** Connect to the target MCU.
 
- 4** Click on "*<Family>_Blinky.c*" to open source file.
 
- 5** Build and Download the program.
 
- 6** Execute the example program. The green LED on the MCU card flashes as the program runs.
 
- 7** Stop execution of the example program.
 
- 8** Set a breakpoint.
 
- 9** Execute the program. The IDE will stop when it encounters the breakpoint.
 
- 10** Step through the program.
 
- 11** Open Debug windows.
 
- 12** View or modify Peripherals, Registers, or Memory.
 

If you are having trouble installing and/or using the development kit, please use the following support resources:

- UDP Motherboard, MCU card, Pico Board, and I/O card User's Guides (www.silabs.com/udp)
- Application Note "AN104: Integrating Keil 8051 Tools Into the Silicon Labs IDE" (contains instructions for obtaining the 4 k limited version of the Keil toolset)
- Latest versions of Application Notes can be found at www.silabs.com/products/microcontroller/applications.asp
- MCU Knowledgebase (available at www.silabs.com → SUPPORT)
- Contact an Applications Engineer using the online information request form (available at www.silabs.com → SUPPORT).